

Progress Hybrid Exterior Corner Stone Replacement

Please read all the instructions before you begin the procedure. Confirm that you have all the necessary tools and materials. If you have any questions, technical support is available toll free at 1-800-866-4344, Monday-Saturday 9:00 – 5:00 ET

Tools Needed:

- 1/8" hex key (Allen Wrench)
- 1/2" socket and ratchet

Materials Needed:

- P-354 Exterior Corner Stone
- Rope or nylon strap (long enough to wrap around stove body)

1. Tie a piece of rope around the stove so as to hold all the components together when the top frame is removed. The rope should be located about 1/3 of the way down from the top of the stove.
2. Locate the tie rod ends under the base of the stove on the same side as the corner to be replaced. They are fastened with hex nuts, and are located close to the leg bolts. Loosen the tie rod by loosening the nuts. Do not remove the nuts completely.



3. Locate the set screws at the center, top of the (4) cast corners on each side of the side stone and loosen them using a 1/8" hex key (Allen wrench). Remove the cast corner that holds the stone being replaced.



4. It may be necessary to lift up the top frame slightly to remove the cast corner from the stove. (If you are top exiting and have already attached the pipe you may have to disconnect it from the stove.)
5. Remove the stone and replace it with the new one.
6. Replace the cast corner.
7. Press down slightly on the top cast as you re-tighten the draw rod nuts loosened in step 2.
8. Secure the cast corners with their set screws using a 1/8" hex key.

We need your help! Woodstock Soapstone Co. takes great pride in providing the highest quality products as well as the best customer service in our industry. We welcome your suggestions and input to help us achieve these goals. If you have any comments to improve our products, service, and information provided in these instructions please contact us at (800) 866-4344 or info@woodstove.com. Thank you.
(Revised 10/26/12)