

PG-23 Tertiary Air Inlet Assembly

Rev. Date 02/12/2025

Parts Needed:
Tertiary Air Damper (Gasketed)

Tools Needed:
7/16" Wrench or socket
Philips Head Screw driver (if top venting)



1. If top venting, remove the two Philips head screws that secure the rear flue cover shield to the stove. The two Philips head screws, circled in red below. Set aside for reinstallation.

If you are rear venting, the shield will not be attached and you can skip to Step 2.



Woodstock
Soapstone
Company, Inc.

66 Airpark Rd., West Lebanon, NH 03784
Phone: 1-800-866-4344
Email: info@woodstove.com
Web: www.woodstove.com

2. Remove the back panel located on the left (when standing behind the stove) with a 7/16 wrench or socket. First remove the top two 1/4-20, then remove the two 1/4-20 nuts and hex-bolts at the bottom.



3. Use a 7/16" wrench or socket and remove the hex head bolt that holds the tertiary air damper to the back of the stove. Keep the bolt for the new installation.



4. Install the new gasketed tertiary air damper using the hex head bolt from step 3, tighten until snug and check to make sure the square plate is over the square hole in the body of the stove.
5. Reinstall the rear cover using the 1/4-20 nuts and hex head bolts that were previously removed in step 2.
6. If top venting, reinstall the block-off shield using the two Philips head screws previously removed in Step 1.
7. Enjoy your stove!